

ECO8000
Automatic Changeover Unit
Release Notes

Copyright © 2025 Telestream, LLC and its Affiliates. All rights reserved. Telestream products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specification and price change privileges reserved. TELESTREAM is a registered trademark of Telestream, LLC. All other trade names referenced are the service marks, trademarks, or registered trademarks of their respective companies.

Telestream products are covered by U.S. and foreign patents, issued and pending. Information in this publication supersedes that in all previously published material. Specifications and price change privileges reserved.

TELESTREAM is a registered trademark of Telestream, LLC.

#### **Contact Telestream**

Telestream LLC 848 Gold Flat Road Nevada City, CA 95959 USA

For product information, sales, service, and technical support:

Worldwide, visit <a href="https://www.telestream.net/telestream-support/video/support.htm">www.telestream.net/telestream-support/video/support.htm</a> to find contacts in your area.

# **Release Notes**

This document describes the new features, fixes, improvements, and limitations of firmware version 2.0 for the ECO8000 Automatic Changeover Unit.

#### **Product Updates**

**Upgrades** The version 2.0 firmware upgrade package can be downloaded from

> www.telestream.net/video/resources.htm. The package consists of a ZIP file containing three files: firmware.pkg, ECO8000-MIB.mib, and transfer.exe. The transfer.exe program is used to upgrade the ECO8000 firmware package from a

network connection to a Windows PC.

Complete instructions can be found in the ECO8000 User Manual.

**Downgrades** It is possible to downgrade from firmware version 2.0 to version 1.1 using the

same process as upgrading.

**New Features** 

Version 2.0 is a major release to support the Telestream-branded ECO8000. Version 2.0 also supports all configurations of Tektronix-branded ECO8000 and ECO8020 models. See the ECO8000 User Manual for details about the

following functions and their operation:

The ECO8000 Management Information Base (MIB) for SNMP now uses the Updated SNMP MIB

Telestream object identifier (OID) instead of the Tektronix OID. If an existing ECO8000 or ECO8020 is upgraded to version 2.0, you will need to re-load the MIB file in the management system to access SNMP objects by their new OID values.

LTC channels now

standard

Support for LTC channel changeover is now a standard feature. It is no longer necessary to purchase an extra licensed option. User interface menus to enter the

software license key have been removed.

## **Updated Features**

The following changes have been made to product features.

**Expansion Port** 

ECO8000 units manufactured prior to May 2025 (with a Tektronix Video logo on a gray front panel) have an expansion port connector on the back panel. This port can be used to "chain" two ECO8000 units together to behave as a single changeover unit with more channels. ECO8000 units manufactured in May 2025 or later (with a Telestream logo on a black front panel) do not have this connector and its associated feature. Version 2.0 firmware will work correctly with both types of ECO8000 units.

## **Resolved Issues and Improvements**

This firmware release has resolved the following issues and makes the following improvements to the previous 1.1 release.

**FAULT RESET** 

The FAULT RESET button on the web interface now works correctly in both

Manual and Automatic modes, just as the front-panel button works. button

RTC battery diagnostics

The real-time clock (RTC) battery diagnostics now correctly reports the battery

level, with a warning status if the voltage is low.

**Channel labels** 

User-defined channel labels are now correctly updated when edited from the web

interface.

**Email password** 

The email username and password settings have been removed from the web interface and front-panel menus since they have no effect. The ECO8000 will only

work with a local SMTP server that does not require user authentication.

#### **General Limitations**

This firmware release has the following general limitations.

Management network connection

If the ECO8000 powers up with the network cable disconnected from the management port, or if the cable is disconnected and re-connected, the DHCP client will not request an IP address. Use a static IP address, or disable and re-enable

DHCP from the front panel NETWORK CONFIG menu.

SNMP community

strings

The SNMP public community string (used for read-only access) and private community string (used for read/write access) must be different. The SNMP agent

will not function correctly if the same string is used for both purposes.